

Everything You Always Wanted to Know About Optical Networking – But Were Afraid to Ask

Richard A Steenbergen <ras@turkbergen.com>

Purpose of This Tutorial

- Why give a talk about optical networking?
 - The Internet as an industry is largely based around fiber.
 - Yet many router jockeys don't get enough exposure to it.
 - This leads to a wide variety of confusion, misconceptions, and errors when working with fiber optic networks.
- Will this presentation make me an optical engineer?
 - Probably not.
 - The purpose of this tutorial is to touch on a little of every topic, from the mundane to the unusual.
 - But it helps to have a basic understanding of these topics, even if you aren't designing fiber networks.

The Basics of Fiber Optic Transmission

What is Fiber, and Why Do We Use It?


- Fiber is essentially a “waveguide” for light.
 - AKA “light that goes in one end, comes out the other end”.
 - Most commonly made of glass/silica, but can also be plastic.
- Why do we use fiber for communications systems?
 - Fiber is a low-cost and extremely light medium to carry signals.
 - A tremendous amount of information can be encoded into light.
 - Many different signals can be encoded onto the same strand of fiber, using different “forms” and “frequencies” of light.
 - These signals can be carried for very long distances without losing the signal and needing to be regenerated.
 - Technology continues to radically improve what we can do with our existing fiber infrastructure, without digging or disruption.

Hold it Down Like I'm Giving Lessons in Physics

- A quick recap from Physics class:
 - Light propagating through a vacuum is (theoretically) the maximum speed at which anything in the universe can travel.
 - That speed is 299,792,458 meters per second, otherwise known as “ c ”.
 - For doing shorthand math, you can round this up to 300,000 km/s.
 - But when light passes through materials that **aren't** a perfect vacuum, it actually propagates much slower than this.
 - The speed for a particular material is expressed as a ratio relative to “ c ”, known as that material's “refractive index”.
 - E.g. Water has a refractive index of “1.33”, or 1.33x slower than “ c ”.
 - And when light tries to pass from one medium to another with a different index of refraction, a reflection can occur instead.
 - This is why you see a reflection when you look up from under water.


Fiber Works by “Total Internal Reflection”

- Fiber optic cables are internally composed of two layers.
 - A “core”, surrounded by a different material known as the “cladding”.
 - The cladding always has a higher “index of refraction” than the core.




- When the light tries to pass from the core to the cladding, and the angle is correct, it is reflected back into the core.

Demonstration Using a Laser Pointer



The Inside of a Common Fiber Cable



What Do We Actually Transmit Over Fiber?

- Most basic systems operate in “duplex” (as a pair of fibers)
 - One fiber used to transmit a signal, the other to receive one.
 - Using this technique, no advanced optical components are required.
 - But more advanced systems can “multiplex” both transmit and receive onto a single strand, doubling capacity.
- The digital signals must be encoded into analog pulses of light
 - Historically “Intensity Modulation with Direct Detection” (IMDD)
 - The most common method of which is “Non-Return to Zero” (NRZ).
 - Which is really just a fancy way of saying “bright for a 1, dim for a 0”.
 - These are then modulated many tens of thousands of times per second.
 - This technique was used for essentially all optical signals up to 40Gbps.
 - The receiving side “sees” these pulses of light, and translates them back into electrical digital signals.

Multi-Mode vs Single Mode Fiber


Multi-Mode Fiber

- Multi-Mode Fiber
 - Usually found as orange fiber jackets inside the datacenter.
 - Two common core sizes, 62.5 microns (μm) and 50 μm .
 - Typically carries signals at 850nm, but sometimes 1310nm.
- Specifically designed for use with “cheaper” light sources.
 - The “wide” core lets you use cheaper, less precisely focused, aimed, and/or calibrated light sources on each end.
- But this comes at the expense of long-distance reach.
 - “Modal distortions” significantly limit the maximum distances.
 - Typically limited to between “tens to hundreds” of meters.
- Recently augmented with OM3 and OM4 “laser optimized” standards for achieving similar distances for 10/40/100G.

Single Mode Fiber


- Single Mode Fiber (SMF)
 - Has a core size of between 8-10 microns (μm)
 - No inherent distance limitations caused by modal distortions
 - Can easily support distances of several thousand kilometers, with appropriate amplification and dispersion compensation.
 - But requires more expensive laser light sources.
 - Typically in the 1270nm – 1625nm range.
 - “Classic” Single-Mode Fiber is frequently called SMF-28
 - Which is actually a Corning product name.
 - But a wide variety of specialty fibers have been developed as well.
 - Low Water Peak Fiber (LWPF), Dispersion Shifted Fiber (DSF), Non-Zero Dispersion Shifted Fiber (NZDSF), etc, etc, etc.

Modal Distortion in Multimode Fiber



Mode Conditioning Cables

- What happens to a “narrow” laser inside “wide” MMF?
 - It gets bounced around, causing modal distortions.
- This can be improved with a Mode Conditioning Cable
 - A manufactured splice between the SMF and MMF cables, precisely setting the angle of the light sent into the MMF.
 - By controlling the angle, modal distortions can be reduced, allowing greater distances to be achieved over MMF.



What Happens When You...?

Transmit Optic Type	Multimode Fiber	Single-mode Fiber
LED Source (traditional 850nm/SX Gigabit optics, FDDI, etc)	Limited by modal distortion, achieves a few hundred meters depending on the exact signal and type of fiber.	Limited by attenuation, diffuse signal doesn't fit into the narrow fiber core, you may achieve a few meters at best.
Laser Source (LX/LR, ER, ZX/ZR, etc)	Limited by modal distortion, but should perform as well or better than an LED source. Not recommended, but it will "work" with a dB hit if you pass a long-reach signal through a short stretch of MMF (patch cable, etc).	Achieves maximum distance determined by signal attenuation and other criteria (10km, 40km, 80km, etc).

Optical Networking Terms and Concepts

Optical Power

- What is optical power?
 - Quite simply, the brightness (or “intensity”) of light.
 - As light travels through fiber, some energy is lost.
 - Absorbed by glass particles and converted into heat;
 - Or scattered by microscopic imperfections in the fiber.
 - This loss of intensity is called “attenuation”.
- We typically measure optical power in “Decibels”
 - A decibel (dB, $1/10^{\text{th}}$ of a Bel) is a logarithmic-scale unit expressing the relationship between two values.
 - The decibel is a “dimensionless-unit”, meaning it does not express an actual physical measurement on its own.

Optical Power and the Decibel

- A decibel is simply a ratio between two values
 - 0 dB is no change, +3 dB is double, -3 dB is half, etc.
 - To express an absolute value (i.e. an actual light level), it must be compared to a known reference value.
- In optical networking, this is typically the “dBm”.
 - That is, a decibel relative to 1 milliwatt (mW) of power.
 - 0 dBm is 1 mW, 3 dBm is 2 mW, -3 dBm is 0.5mW, etc.
 - So what does this make 0mW? Negative Infinity dBm.
 - Confusion between dB and dBm is one of the most common mistakes when working with optical networks!

Optical Power and the Decibel

- Why do we measure light with the Decibel?
 - Light, like sound, follows the inverse square law.
 - The signal is inversely proportional to the distance squared.
 - A signal travels distance X and loses half of its intensity.
 - The signal travels another distance X and loses another half.
 - After $2X$ only 25% remains, after $3X$ only 12.5% remains.
 - Using a logarithmic scale simplifies the calculations.
 - A 3dB change is approximately half/double the original signal.
 - In the example above, there is a 3dB loss per distance X .
 - At distance $2X$ there is 6dB of loss, at distance $3X$ it is 9dB.
 - This allows us to use simple addition/subtraction when measuring gains/losses.

Decibel to Power Conversion Table

Table 1 - Decibel to Power Conversion



dB (loss)	Power Out as a % of Power In	% of Power Lost	Remarks
1	79%	21%	---
2	63%	37%	---
3	50%	50%	1/2 the power
4	40%	60%	---
5	32%	68%	---
6	25%	75%	1/4 the power
7	20%	80%	1/5 the power
8	16%	84%	1/6 the power
9	12%	88%	1/8 the power
10	10%	90%	1/10 the power
11	8%	92%	1/12 the power
12	6.3%	93.7%	1/16 the power
13	5%	95%	1/20 the power
14	4%	96%	1/25 the power
15	3.2%	96.8%	1/30 the power
16	2.5%	97.5%	1/40 the power
17	2%	98%	1/50 the power
18	1.6%	98.4%	1/60 the power
19	1.3%	98.7%	1/80 the power
20	1%	99%	1/100 the power
25	0.3%	99.7%	1/300 the power
30	0.1%	99.9%	1/1000 the power
40	0.01%	99.99%	1/10,000 the power
50	0.001%	99.999%	1/100,000 the power

Dispersion

- Dispersion simply means “to spread out” .
 - In optical networking, this results in signal degradation.
- There are two main types of dispersion to deal with
 - Chromatic Dispersion
 - Different frequencies of light propagate through a non-vacuum at slightly different speeds. This is why optical prisms work.
 - But if one part of an optical signal travels faster than the other part, the signal will eventually “smear out” over long distances.
 - Polarization Mode Dispersion
 - Caused by imperfection in shape of the fiber (not perfectly round).
 - One polarization of light propagates faster than the other.
 - Older fiber is particularly affected, may get worse with age.

The Effects of Dispersion


- As the signal is dispersed, it is no longer distinguishable as individual pulses at the receiver.



Fiber Optic Transmission Bands

- There are several frequency “windows” available
 - 850nm – The First Window
 - Highest attenuation, only used for short reach applications today.
 - 1310nm – The Second Window (O-band)
 - The point of zero dispersion on classic SMF, but high attenuation.
 - Primarily used for medium-reach applications (up to 10km) today.
 - 1550nm – Third Window (C-band)
 - Stands for “conventional band”, covers 1525nm – 1565nm.
 - Has the lowest rate of attenuation over SMF.
 - Used for almost all long-reach and DWDM applications today.
 - Forth Window (L-band)
 - Stands for “long band”, covers 1570nm – 1610nm.


Fiber Optic Transmission Bands



Forward Error Correction


- Forward Error Correction
 - Adds extra/redundant information to a transmission so that a receiver can “recover” from small errors.
 - Think of it like RAID5 for your wavelengths. Even if you lose some bits, you can still recover them computationally.
 - FEC works by extending the receiver sensitivity to levels which would normally have too many bit errors to use.
 - Using clever math, padding a 10.325Gbps signal to 11Gbps (7% overhead) can extend a 80km wavelength to 120km or beyond, at the same or better bit error rate.
 - Typically implemented as a digital “wrapper” (G.709) on an existing signal.

The Benefits of Forward Error Correction



OTN Digital Wrapper Technology (G.709)



- OTN stands for Optical Transport Network
 - A set of standards which allow interoperability and the generic transport of any protocol across an optical network.
 - Implemented as a “wrapper” around another protocol.
 - Why is this needed?
 - So the optical network can be completely transparent.
 - Also, some protocols don't have the same level of troubleshooting capabilities as other protocols.
 - For example, Ethernet is not as good as SONET, because Ethernet wasn't originally designed for the WAN.
 - An OTN wrapper allows the optical troubleshoot with OTN instead.



Wave Division Multiplexing


Wave Division Multiplexing (WDM)

- What is Wave Division Multiplexing (WDM)?
 - We know that light comes in many different colors.
 - These different colors can be combined on the same fiber.
 - The goal is to put multiple signals on the same fiber without interference (“ships in the night”), thus increasing capacity.




Different Types of WDM

- There are several different types of WDM
 - The most common terms are Dense and Coarse.
 - Essentially they both do the same thing in the same way.
 - The only difference is the channel spacing.
 - And sometimes the range of the optical spectrum they cover.



Coarse Wavelength-Division Multiplexing

- CWDM is loosely used to mean “anything not DWDM”
 - One “popular” meaning is 8 channels with 20nm spacing.
 - Centered on 1470 / 1490 / 1510 / 1530 / 1550 / 1570 / 1590 / 1610



- With Low Water Peak fiber, another 10 channels are possible
 - Centered on 1270/1290/1310/1330/1350/1370/1390/1410/1430/1450.
- Can also be used to refer to a simple 1310/1550nm mux.

Dense Wavelength-Division Multiplexing

- So what does that make Dense WDM (DWDM)?
 - A much more tightly packed WDM system.
 - Defined by the ITU-T G.694.1 as a “grid” of specific channels.
 - Within C-band, these channel spacings are common:
 - 200GHz – 1.6nm spacing, 20 channels
 - 100GHz – 0.8nm spacing, 40 channels
 - 50GHz – 0.4nm spacing, 80 channels
 - 25GHz – 0.2nm spacing, 160 channels
 - A rough guideline:
 - 200GHz is “2000-era” old tech, rarely seen in production any more.
 - 100GHz is still quite common for metro DWDM tuned pluggables.
 - 50GHz is common for commercial, long-haul, and 100G systems.
 - 25GHz was used for high-density 10G systems, before the move to more modern 100G systems at 50GHz spacings.

What Are The Advantages?


- CWDM

- Cheaper, less precise lasers can be used.
 - The actual signal in a CWDM system isn't really any wider.
 - But the wide channel allows for large temperature variations.
 - Cheaper, uncooled lasers can more easily stay within the window.

- DWDM


- Far more channels are possible within the same fiber.
 - 160 channels (at 25GHz) in 32nm of spectrum, vs. 8ch in 160nm.
- Can stay completely within the C-band
 - Where attenuation and dispersion are far lower than other bands.
 - Where Erbium Doped Amplifiers (EDFAs) work.

CWDM vs. DWDM Relative Channel Sizes



Other Uses of WDM

- WDM is also used in other channel combinations
 - 10GBASE-LX4 optics, 10GbE over 4x3.2G WDM lanes
 - Uses non-standard 1275 / 1300 / 1325 / 1350nm channels.
 - Used to achieve longer distances over older grade MMF.
 - 40GE and 100GE will likely offer similar integrated WDM optics.
 - 1310/1550 muxes
 - Simple combination of two popular windows onto a single strand.
 - 1GBASE-BX optics for use on single-strand fibers
 - 1310 / 1490nm mux integrated into a pluggable transceiver.



WDM Networking Components



WDM Mux/Demux

- The Mux/Demux
 - Short for “multiplexer”, sometimes called a “filter” or “prism”.
 - The term “filter” is how it actually works, by filtering specific colors.
 - But most people understand a “prism” splits light into the spectrum.
 - A simple device which combines or splits multiple colors of light into a single fiber (called the “common” fiber).
 - Muxes are entirely passive devices, requiring no power.
 - A complete system requires a mux+demux for TX and RX.
 - Most modern devices function the same in both directions, as a mux or demux, so the actual device is the same.
 - Many vendors combine the mux+demux into a single unit for simplicity, but it is really 2 distinct components.

How a Mux Works


- Muxes are actually optical bandpass filters
 - Typically based on Bragg Grating or Dichroic filters.
 - Some frequencies are reflected, the rest are passed through.
 - The channels actually overlap slightly, but have enough isolation to prevent cross-talk interference.

Bragg Grating Effects




The Optical Add/Drop Multiplexer (OADM)

- The Optical Add/Drop Multiplexer (OADM)
 - Selectively Adds and Drops certain WDM channels, while passing other channels through without disruption.
 - Where a mux is used at the end-point of a WDM network to split all of the component wavelengths, an OADM is used at a mid-point, often in a ring.
 - With a well-constructed OADM ring any node can reach any other node in the ring, potentially reusing the same wavelength multiple times across different portions of the ring




The ROADM

- A somewhat recent addition to optical networking.
 - The “Reconfigurable Optical Add/Drop Multiplexer”.
 - Essentially a “tunable OADM”, usually in software.
 - Allows you to control which channels are dropped and which are passed through, increasing channel flexibility.
- Some ROADMs are multi-degree
 - Instead of only being able to “pass” or “drop”, there are more than 2 directions of “pass” to choose from.
 - This allows you to build complex star topologies at a purely optical level.



Optical Amplifiers


- Optical amplifiers increase the intensity of a signal
 - There are different types, for different spectrums of light.
 - The most common is the Erbium Doped Fiber Amplifier.
 - Another method is Raman Amplification, typically for ultra long-haul.
 - In an EDFA, a piece of fiber is “doped” with Erbium ions.
 - Additional laser power at 980nm and/or 1480nm is pumped in via a coupler.
 - The interaction between the Erbium and the pump laser causes the emission of light in the C-band spectrum, amplifying the signal.



Optical Switches


- Optical Switches

- Let you direct light between ports, without doing O-E-O conversion.
- Built with an array of tiny mirrors, which can be moved electrically.
- Allows you to connect two fibers together optically in software.
- Becoming popular in optical cross-connect and fiber protection roles.
- Also used inside of complex multi-degree ROADMs, called a WSS (wavelength selectable switch).



Circulator

- A component typically not seen by the end user
 - But used to implement various other common components.
 - Such as muxes, OADMs, and dispersion compensators.
- A circulator has 3 fiber ports.
 - Light coming in port 1 goes out port 2.
 - Light coming in port 2 goes out port 3.



Splitters and Optical Taps

- Optical Splitters
 - Do exactly what they sound like they do, split a signal.
- Common examples are:
 - A 50/50 Splitter
 - Often used for simple “optical protection”.
 - Split your signal in half and send down two different fiber paths.
 - Use an optical switch with power monitoring capabilities on the receiver, have it automatically pick from the strongest signal.
 - If the signal on one fiber drops, it switches to the other fiber.
 - A 99/1 Splitter
 - Often used for “Optical Performance Monitoring”.
 - Tap 1% of the signal and run it to a spectrum analyzer.

Types of Single Mode Optical Fiber

Types of Single-Mode Fiber

- We've already discussed how single-mode fiber is used for essentially all long-reach fiber applications.
- But there are also several different types of SMF.
- The most common types are:
 - “Standard” SMF (ITU-T G.652) A.K.A. SMF-28
 - Low Water Peak Fiber (ITU-T G.652.C/D)
 - Dispersion Shifted Fiber (ITU-T G.653)
 - Low-Loss Fiber (ITU-T G.654)
 - Non-Zero Dispersion Shifted Fiber (ITU-T G.655)
 - Bend Insensitive Fiber (ITU-T G.657)


“Standard” Single-Mode Fiber (G.652)

- One of the original fiber cables.
 - Deployed widely throughout the 1980s.
- Frequently called “SMF-28”, or simply “classic” SMF.
 - SMF-28 is actually a product name from Corning.
 - Also called NDSF (Non-Dispersion Shifted Fiber).
- Optimized for use by the 1310nm band.
 - Has the lowest rate of dispersion here.
 - Originally deployed before the adoption of WDM.


Low Water Peak Fiber (G.652.C/D)

- Modified G.652, designed to reduce water peak.
 - Water peak is a high rate of attenuation at certain frequencies due to OH- hydroxyl molecule within the glass.
 - This high attenuation makes certain bands “unusable”.

Absorption of Light by Hydrogen at Various Wavelengths



Attenuation of Standard vs. Low Water Peak Fiber



Dispersion Shifted Fiber (ITU-T G.653)

- An attempt to improve dispersion at 1550nm.
 - The rate at which chromatic dispersion occurs will change across different frequencies of light.
 - The point of lowest dispersion in G.652 occurs at 1300nm.
 - But this is not the point of lowest attenuation, which is around 1550nm.
 - DSF shifts the point of lowest dispersion to 1550nm too.
- But this turned out to cause big problems.
 - Running DWDM over DSF causes non-linear interactions.
 - One notable example is called Four Wave Mixing
 - 3 equally spaced wavelengths interact to produce a 4th wavelength.
 - As a result, this fiber is rarely used today.


Non-Zero Dispersion Shifted Fiber (G.655)

- Similar concept to Dispersion Shifted Fiber
 - But the zero point is moved outside of the 1550nm band.
 - This leaves a small amount of dispersion, but avoids the non-linear cross-channel interactions cause by DSF.
- To manage dispersion, NZDSF comes in 2 types
 - NZD+ and NZD-, with opposite dispersion “slopes”.
 - One spreads the 1550nm band out.
 - The other compresses it in the opposite direction.
 - By switching between the two slopes, the original signal can be maintained even over extremely long distances.

Other Single-Mode Fiber Types

- **G.654**
 - Low-attenuation fiber, at the expense of dispersion.
 - Designed for high-power systems like undersea cables.
- **G.657**
 - Bend Insensitive fiber (reduced sensitivity at any rate).
 - Uses a higher refractive index cladding than normal fiber.
 - Designed for premise use where the high bend radius of a well designed datacenter may not be practical.
- Modern fibers are usually better than the spec.
 - But much of what's actually in the ground is old fiber.

Dispersion Rates of Commercial Fibers




Engineering an Optical Network


Insertion Loss

- Even the best connectors and splices aren't perfect.
 - Every time you connect two fibers together, you get loss.
 - The typical budgetary figure is 0.5dB per connector.
 - Actual loss depends on your fiber connector and mating conditions.
- Insertion loss is also used to describe loss from muxes.
 - Since it is the “penalty you pay just for inserting the fiber”.
 - Some real-life examples:
 - 8-channel CWDM 20nm Mux/Demux: 3.5dB
 - 16-channel DWDM 100GHz Mux/Demux: 7.5dB
 - 32-channel DWDM 100GHz Mux/Demux: 9.5dB

Mismatched Cores



Misaligned Cores




Air Gap Between Fibers




Balling On An Optical Budget

- To plan your optical network, you need a budget.
 - When an optic says “40km”, this is only a guideline.
 - Actual distances can be significantly better or worse.
 - It’s also smart to leave some margin in your designs.
 - Patch cables get bent and moved around, optic transmitters will cool with age, a fiber cut fix will add more splices, etc.



Amplifiers and Power Balance

- Amplifiers introduce their own unique issues.
 - Amplifier gain is not consistent across all wavelengths.
 - The gain must be equalized, or after several amplification stages the power of some channels will be far higher.
 - Mismatched channel powers causes SNR issues.
 - Care must also be taken when using OADMs, to balance power on passed-thru vs. newly added channels.




Amplifiers and Total System Power

- Amplifiers also have limits on their total system power
 - Both what they can output, and what they can take as input.
 - But the total input power changes as you add channels
 - A single DWDM channel at 10dBm is 0.1mW of input power.
 - 40 DWDM channels at 10dBm is 4mW of power (or 6dBm).
 - If your amplifier's maximum input power is -6dBm, and you run 40 DWDM channels through it, each channel must be below -22dBm.
 - Failing to plan for this can cause problems as you add channels.
 - The total input power also changes as you lose channels.
 - Imagine power fails to a POP, and many channels are knocked offline.
 - Suddenly the total system power has changed.
 - A good EDFA needs to monitor system power levels and apply dynamic gain adjustments to maintain a working system.

Dealing with Dispersion

- Dispersion Compensation Unit
 - Essentially just big a spool of fiber in a box.
 - Designed to cause dispersion in the opposite direction (with the opposite “slope”) as the transmission fiber used.
 - Passing the signal through this spool reverses the effects of dispersion caused by transmission through the normal fiber.
 - But it also adds extra distance to the normal fiber path, causing additional attenuation, requiring more amplification.
 - Dispersion Compensation spools are typically positioned at optical amplification points for this reason.
 - Circulators can be used to reduce the total amount of fiber needed.



Dealing with Dispersion

- **Electronic Dispersion Compensation**
 - Dispersion which used to completely ruin a signal can now be compensated for electronically at the receiver.
 - Modern long-haul DWDM systems can handle 4500km of dispersion compensation entirely electronically.
 - Through sophisticated Digital Signal Processors (DSPs) which compensate for the signal distortion computationally.
 - EDC is being integrated into pluggable optics too.
 - Largely responsible for the 300 meter ranges which can now be achieved over MMF with modern optical standards like 10GBASE-LRM.
 - Technology is getting better all the time too.

Re-amplifying, Reshaping, and Retiming

- Signal Regeneration (Repeaters)

- Different types are described by the “R” s” that they perform.

- 1R – Re-amplifying


- Makes the analog signal stronger (i.e. makes the light brighter)
- Typically performed by an amplifier.

- 2R – Reshaping

- Restores the original pulse shape that is used to distinguish 1’ s and 0’ s.

- 3R – Retiming

- Restores the original timing between the pulses.
- Usually involves an O-E-O conversion.



Bit Error Rates

- As optical impairments (noise, distortion, dispersion, loss of signal, etc) increase...
- The link typically doesn't just outright "die".
 - It starts taking bit errors, at progressively higher rates.
 - The target maximum Bit Error Rate (BER) is generally 10^{-12} .
 - You can get by with another dBm less signal at 10^{-11} BER.
 - And another dBm less signal after that at 10^{-10} BER.
 - But with exponential progression, the errors gets very bad quickly.

Coherent Optical Technologies

Coherent Optical Technologies


- What exactly are “coherent” optics?
 - A group of advancements in optical technology, which combine to deliver significantly increased optical performance.
 - Specifically, coherent technologies consist of:
 - High-order phase modulation.
 - Polarization multiplexing.
 - Improved signal detection using a local laser as a reference oscillator.
 - Advanced Digital Signal Processors (DSPs) which are necessary to tie all of these together, recombine the signals, and compensate for impairments.
 - These technologies combine to deliver:
 - Significantly improved spectrum efficiency (from 1.6Tbps to 9.6Tbps+)
 - True 100G and beyond optical signals, not just Nx10G signals.
 - High-bandwidth optical signals which are usable over long distances.
 - No need for physical Dispersion Compensation Units.

Improved Modulation Techniques

- Historically optical systems used “IM-DD” modulation.
 - Simplistic “bright for a 1, dim for a 0” type modulation.
 - This yields only 1 data bit per “symbol”, or modulation change.
 - 10GE meant modulating the light 10 billion times/sec, or 10 Gigabaud.
- But adding bandwidth by increasing clock cycles has limitations.
 - For years, the industry was not able to break through the “10G barrier” caused by increasing chromatic and polarization dispersion impairments.
 - Technology advanced only by packing the channels tighter (160 channels in C-band), and throwing more Nx10G’s at the problem.
- Improving the modulation technique yields more bits per symbol.
 - Quadrature Phase Shift Keying (QPSK) delivers 2 bits per symbol.
 - 8 Quadrature Amplitude Modulation (8QAM) delivers 3 bits per symbol.
 - 16 Quadrature Amplitude Modulation (16QAM) delivers 4 bits per symbol.
 - Etc, etc.

Polarization Multiplexing

- What is “Polarization Multiplexing”?
 - Light is (among many other things we don’t fully understand yet) actually a wave of electromagnetic energy propagating through space.
 - In 3-Dimensional space (e.g. a cylindrical fiber), you can send two independent orthogonal signals which propagate along a X and Y axis, without interfering with each other.
 - Modern DSPs have made compensating for the changing fiber conditions in real-time practical, allowing dual polarities of light and thus doubling the bandwidth per channel.



Putting It All Together

- Modern long-haul DWDM systems already deliver:
 - 100Gbps transponders with Dual Polarity (DP) Quadrature Phase Shift Keying (QPSK) of 25GBaud signals, to deliver 3000km reach.
 - 200Gbps transponders with DP-16QAM at 700km reach.
- Further improvements, better DSPs, and better photonics integration onto routers and pluggables, are all expected.

Modulation	Normalized Reach	C-Band Capacity
DP-QPSK	3000 km	8 Tbps
DP-8QAM	1500 km	12 Tbps
DP-16QAM	700 km	16 Tbps
DP-32QAM	350 km	24 Tbps
DP-64QAM	175 km	32 Tbps

Tools of the Trade


Fiber Optic Power Meter

- Optical Power Meter (or simply a Light Meter)
 - Measures the brightness of an optical signal.
 - Displays the results in dBm or milliwatts (mW).
 - Most light meters include a “relative loss” function as well as absolute power meter.
 - Designed to work with a known-power light source on the other end, to test the amount of loss over a particular fiber strand.
 - These results are displayed in dB, not dBm.
 - Frequently the source of much confusion in a datacenter, when you use the wrong mode!
 - If I had a nickel for every time someone told me they just measured a +70 signal on my fiber...




Optical Time-Domain Reflectometer (OTDR)

- An OTDR is a common tool for testing fiber.
- Injects a series of light pulses into a fiber strand.
- Analyzes light that is reflected back.
- Used to characterize a fiber, with information like:
 - Splice points, and their locations.
 - Overall fiber attenuation.
 - Fiber breaks, and their locations (distance from the end-point).




Example OTDR Output



Feature #/Type	Location (km)	Event-Event (dB) (dB/Km)	Loss (dB)	Refl (dB)
1/N	2.3310	?? ??	0.12	
2/R	6.8035	0.91 0.203	0.64	-58.19
3/R	10.4907	0.72 0.196	1.86	-48.24
4/N	13.8639	0.70 0.206	0.06	
5/N	14.6205	0.14 0.188	-0.71	
6/N	15.9114	0.26 0.205	1.06	
7/N	17.2350	0.25 0.193	0.08	
8/E	17.4491	0.05 0.211	>3.00	>-33.55S

Overall (End-to-End) Loss: ??



Feature #/Type	Location (km)	Event-Event (dB) (dB/Km)	Loss (dB)	Refl (dB)
1/N	0.1937	0.02 0.121	-0.06 (2P)	
2/N	1.5194	0.24 0.184	-0.82	
3/N	2.8327	0.26 0.197	0.99	
4/R	6.9421	0.90 0.219	-0.21	>-46.37
5/R	10.6396	0.75 0.203	0.96	-56.69
6/R	17.2269	1.28 0.194	1.61	-61.90
7/E	17.4512	0.04 0.184	>3.00	>-34.48S

Overall (End-to-End) Loss: 5.97 dB

Question: Can I really blind myself by looking into the fiber?

Beware of Big Scary Lasers



Laser Safety Guidelines

- Lasers are grouped into 4 main classes for safety
 - Class 1 – Completely harmless during normal use.
 - Either low powered, or laser is inaccessible while in operation.
 - Class 1M – Harmless if you don't look at it in a microscope.
 - Class 2 – Only harmful if you intentionally stare into them
 - Ordinary laser pointers, supermarket scanners, etc. Anyone who doesn't WANT to be blinded should be protected by blink reflex.
 - Class 3 – Should not be viewed directly
 - Class 3R (new system) or IIIA (old system)
 - Between 1-5mW, “high power” Internet purchased laser pointers, etc.
 - Class 3B (new system) or IIIB (old system)
 - Limited to 500mW, requires a key and safety interlock system.
 - Class 4 – Burns, melts, destroys Alderaan, etc.

Laser Safety And The Eye

- Networking lasers operate in the infrared spectrum
 - Infrared can be further classified as follows:
 - IR-A (700nm – 1400nm) – AKA Near Infrared
 - IR-B (1400nm – 3000nm) – AKA Short-wave Infrared
 - Laser safety levels are based on what can enter the eye.
 - And the human eye didn't evolve to see infrared.
 - The cornea actually does a very good job of filtering out IR-B light.
 - So an IR-B laser which transmits 10mW of power may still be a Class 1, because that light can't enter the eye.

Optical Networking and Safety


- **Routers**
 - Essentially every single channel laser which can be connected to a router is a Class 1 or Class 1M laser.
 - Even the longest reach 200km+ optics, etc.
- **Optical Amplifiers**
 - Optical amplifiers are capable of putting out enough power to kick a signal into Class 3R (metro) or 3B (long-haul).
- **DWDM Equipment**
 - Total optical power can also increase by muxing together many signals, bringing the total output power into the 3R region even without optical amplification.

Optical Networking and Safety

- So should I be wearing goggles to the colo?
 - Generally speaking, direct router ports are always Class 1 (completely safe under all conditions).
 - Even on DWDM systems, the light rapidly disperses as soon as it leaves the fiber and travels through air.
 - Wavelengths above 1400nm are IR-B, and are mostly blocked by the human eye. Most high power optics and long-reach systems are in this range.
 - Extremely high-power DWDM systems have safety mechanisms which detect a fiber cut and cease transmitting a continuous high-power signal until it is repaired.

Why Look Into The Fiber Anyways?

- Can you even see the light at all?
 - No, the human eye can only see between 390 – 750nm.
 - No telecom fiber signal is directly visible to the human eye.
- But, I looked at 850nm and I saw red?
 - What you're seeing are the sidebands of an imperfect signal generation, not the main 850nm signal itself.
 - However, most digital cameras can actually see in infrared.
 - One trick to check for light in a fiber is to hold it up to your camera phone.
 - You can try this on your TV's remote control.




Question: Can optical transceivers be damaged by over-powered transmitters?

Damage by Overpowered Transmitters?

- Well, yes and no.
 - Actually, most optics transmit at roughly the same power.
 - The typical output of 10km vs 80km optics are within 3dB.
 - Long reach optics achieve their distances by having extremely sensitive receivers, not stronger transmitters.
 - 80km optics may have a 10dB+ more sensitive receiver than 10km
 - These sensitive receivers are what are in danger of burning out.
 - There are two thresholds you need to be concerned with.
 - Saturation point (where the receiver is “blinded”, and takes errors).
 - Damage point (where the receiver is actually damaged).
 - The actual values depend on the specific optic.
 - But generally speaking, only 80km optics are at risk.

Tx and Rx Optical Power Ranges

■ Tx Window □ Rx Window



10 5 0 -5 -10 -15 -20 -25 -30

..... Receiver Damage Threshold **dBm** Receiver Blindness Threshold

Question: Do I really need to be concerned about bend radius?

Is Bend Radius Really A Concern?

- Yes, bend radius is a real issue.
 - Remember that total internal reflection requires the light to hit the cladding below a “critical angle”.
 - Bending the fiber beyond it’s specified bend radius causes light to leak out.
 - In fact, they even make “macro-bend light meters” which clamp onto the fiber.
 - There are “bend insensitive” fibers for use in residential or office environments which have less bend sensitivity, but they usually trade some performance under normal conditions to achieve this.



Question: Can two transceivers on different wavelengths talk to each other?

Can You Mismatch Transceiver Freqs?

- Between certain types of optics, yes.
 - Essentially all optical receivers are wide-band.
 - Though the level of sensitivity may differ for some frequencies.
 - Laser receivers see everything between 1260nm – 1620nm.
 - But they won't be able to see a 850nm LED, for example.
 - Many DWDM networks are build around this premise.
 - By using one wavelength going A->B and other going B->A, you can achieve a bidirectional system over a single fiber strand.
 - The DWDM filters (muxes and OADMs) provide hard cut-offs of certain frequencies, but the transceivers can receive any color.
 - The only “gotcha” is optical power meters will be wrong.
 - A meter that is calibrated to read a 1310nm signal will see a 1550nm signal just fine, but it's power reading will be a few dB off.


Can You Mismatch Transceiver Freqs?

- **Obscure Optical Networking Trick #738:**
 - You may be able to achieve nearly as much distance with a LR/ER (1310nm 10km / 1550nm 40km) pair as with an ER/ER pair.
 - 1550nm has a much lower attenuation rate than 1310nm.
 - Around 0.2dB/km vs 0.35dB/km depending on fiber type.
 - So the LR side receives a much stronger signal than the ER side.
 - The ER optic has a much greater RX sensitivity than the LR.
 - So it will be able to hear the 1310nm signal much better.
- **Result:**
 - You may only *need* a long reach optic on one side.

Question: Do I Really Need to Clean the Fiber to have it work right?

Do I Really Need to Clean the Fiber?

http://www.fols.org/fols_library/presentations/documents/brown.pdf



Back Reflection = **-67.5 dB**
Total Loss = **0.250 dB**



Back Reflection = **-32.5 dB**
Total Loss = **4.87 dB**

Fiber Contamination and Its Effect on Signal Performance



Clean Connection vs. Dirty Connection

OTDR trace illustration of the significant decrease in signal performance after mating dirty connectors

Other Misc Fiber Information

How Fast Does Light Travel In Fiber?

- Ever wondered how fast light travels in fiber?
 - The speed of light is 299,792,458 m/sec
 - SMF28 core has a refractive index of ~ 1.468
 - Speed of light / 1.468 = 204,218,296 m/sec
 - Or roughly 204.2 km/ms, or 126.89 miles/ms
 - Cut that in half to account for round-trip times.
 - So approximately 1ms per 100km (or 62.5 miles) of RTT.
- Why do you see a much higher value in real life?
 - Remember, fiber is rarely laid in a straight line.
 - It is often laid in rings which take significant detours.
 - Dispersion compensation can add extra distance too.

Send questions, comments, complaints to:

Richard A Steenbergen <ras@turkbergen.com>